



WerkMaster Viper XT Versatile Grinder & Polisher



The WerkMaster Viper XT is designed specifically to meet the needs of contractors, facility services, equipment rental and DIYers.

7 Machines in 1 – Grinds, strips, sands, polishes, buffs, burnishes, and edges to within 1/8" (3 mm) of the wall!

▼ Features WerkMaster Octi-DiscTM

technology with 8 counter rotating heads and the versatility of using our 5" (127mm) ULTRA-FLEX Plug 'N Go tooling

☑ Runs wet or dry on concrete, stone, terrazzo or VCT tile; dry on hardwood
☑ Easy to use and operator friendly, weighs only 205 lbs (93 kg) with a 17"

(43 cm) footprint and a variable speed motor with a disc rotation speed range of 450 – 1800 RPM

☑ The Viper XT has a 3 HP 220V motor that runs on 110V using a Quick 220 adapter, or plug directly into a single phase 220V outlet or a 4 kW generator

VIPER XT				
Footprint: in (cm)	17 (43.2)			
Disc Size: in (cm)	5 (12.7)			
Weight: lbs (Kg)	205 (93)			
Disc Speed Range: RPM	450-1800			
Horsepower	3			
Voltage: VAC	208/230 (110+)			
Frequency: Hz	50/60			
Electric Phase: Ph	1			
Breaker Size: Amp	20			
Vacuum Req: CFM	150			
Min. Generator: kW	4.0+			
Max Cable Length: ft (m)	350+ (107+)			


Please visit http://www.werkmaster.com/product-videos/ for a demonstration of techniques using WerkMaster Machines for removing various adhesives and substrates from concrete.

WerkMaster Viper XT Maintenance Checklist

ATTENTION: It is important that the WerkMaster Viper XT go out to the end user with all included accessories. Ensure all moving parts in are in good working order.



ULTRA-FLEX DRIVE™ GROMMET



DUST SKIRT

Ensure dust skirt is not chipped and in good working order. A dust skirt that is broken may leak and release substrate material into the work area atmosphere.

ULTRA-FLEX DRIVE™

8 - ULTRA-FLEX DRIVE™ connected to machine output shaft. All ULTRA-FLEX DRIVE™ must include 2 grommets. Check for cracks and splits in grommets and replace if damaged prior to sending it out to rental.

SURFACE PREPARATION

For removing coating like Glue, Epoxy, Paint and Thinset use WerkMaster full 5" inch full plate 16 grit shark tooling.(rented)

GRINDING, REDUCE SCRATCHES

All other WerkMaster Tooling please refer to: http://www.werkmaster.com/machine-specific-tooling/ To purchase from an authorized WerkMaster Dealer

TOOLING

Ensure all tooling has the same even wear and is of the same grit. **Unevenly worn tooling will result in poor performance on the substrate you are working on**. The tooling grit number is stamped on the front of tool.



Operation and Safety Guide

VIPER XT ™

Vendor Website: www.werkmaster.com

Support Phone No. 866-373-9375

WARNING



SAFETY TOPICS:

Read the Operator's Manual or the Operation and Safety Guide and all of the safety precautions before attempting to operate WerkMaster machines. Failure to follow the safety precautions could result in severe personal injury or death. Please visit www.werkmaster.com

SAFETY CHECKLIST:



WARNING: ALWAYS turn the equipment off and unplug the power cord when changing discs/tooling, before servicing, and when not in use.



1. Before connecting the equipment to a power source make sure that is the correct voltage.



2. Ensure that all cords on the equipment are securely fastened and in good repair.

- 3. Ensure that all extension cords and power outlets are rated for the intended use, are in good repair, and are properly grounded (3 prong configuration).
- 4. Never operate the equipment under the influence of drugs or alcohol or when extremely fatigued.
- 5. If the equipment doesn't start or stops while running contact the rental dealer.




WARNING: Never turn the equipment on while it is tilted back. Any discs/tooling attached to the bottom could eject and become a lethal projectile.



equipment such as hearing and eye protection and a dust mask or respirator.

Wear appropriate personal safety

Tool Application: The VIPER XT [™] can be used to grind and/or polish a concrete



	11g.1	rig.2	1 1g.5				
Tool C	Tool Operation:						
Step	Action						
	in its full upright po the appropriate too (B) for Metal bon	osition (Fig.1). Tilt the eq oling holder attachment – d tools or 5" Foam/Velcr 2 shear pins into the rubb	olug (A). Ensure the handle is uipment back (Fig.3). Choose 5" magnetic Plug 'N Go plate o Adapter plate for polishing er grommets. Then attach the				
	dust skirts (C) so speed control kno	that it is just above th	sition. Loosen and lower the e working surface. Turn the t the 4 pin connector cord (K) le (L).				
	inserting the pull electrical power equipped). Conne	pin at the swivel joint (E cord through the strap	ating position by removing & E). Slide the vacuum hose & (F) on the holding arm (if ne vacuum pipe (G). Plug the				
	equipment gently		the handle bars. To start the ever (I). Adjust the speed as e activation lever.				
	chattering. If ch	nattering or excessive g the power cord, tilt it	d move smoothly and without vibration occurs stop the back and verify that all the				
	motion. Be sure k		y direction using a circular s to prevent unwanted marks. n/viper-xt/.				
7	Lifting Handle (J)	located at the front of the	equipment.				


Taking it to the Wall!

HOW TO USE THE QUICK 220 ADAPTER



Allows you to easily power 220V equipment from ordinary household 115V or 120V outlets. To use the converter, plug it into two common household outlets, connect 220V equipment and begin to use.

Access to 220V power is made easy, fast and safe without the heat and weight of a step-up transformer.



Use only grounded extension cords when using the Quick 220 Adapter



GFI outlets are not compatible with the Quick 220 Adapter.

Step 1 - Identify Two separate 110V Power Sources

Use appropriate extension cords with grounds as necessary to reach 110/120 volt outlets.

The Quick 220 requires two separate 110V volt line feeds in order to create 220 volts of power to run your machine. Each plug must be connected to a breaker on either side of your electrical panel.

Step 2 - Making the Power Connection

- Connect "PLUG 1" power cord to 110/120 volts AC outlet. The Quick 220 power supply will give an audible "click" as "PLUG A" is inserted into the outlet.
- Connect "PLUG 2" power cord to other 110/120 volt AC outlets until "220 Volts" lamp on front panel illuminates. (An extension cord will probably be necessary.)

As "PLUG 2" is inserted into the outlet, the Quick 220 power supply will give an audible "click." If there is no "click," disconnect and try another outlet.

- When "220 Volts" illuminates, 220/240 volts is ready for use on 220/240 volt outlet.
- If "220 Volts" does not illuminate, move "Plug 2" to other outlets until "220 Volts" lights.

Contact our Customer Support Team to Learn More 1 866 373 WERK or 604 629 8700

WerkMaster Viper XT Parts Re Order List

PARTS DESCRIPTION LIST FOR HOME DEPOT USE ONLY

Viper XT 008- Service Kit		Includes 1 set of all Suggested On-Hand QTY items listed below	1
---------------------------------	--	--	---

Ordering individual components of the Viper XT Service Kit does not include shipping & handling. The costs are the responsibility of each THD Store.

IMAGE	PART #	DESCRIPTION	SUGGESTED ON-HAND QTY
8	520-0036-00	▶ 001-0055-00	2
	008-0114-00	3/8" Shear Pin & 1/4" Screw Combo	20
•	008-0207-00	3/8 Black Grommet Viper XT	20
*	008-0208-00	1" Black Bumper Durom 70	20
	002-1456-00	5" - 16 Grit Medium (Orange) Full Plate Tooling	8
\supset	008-0264-01	Viper XT Dust Skirt	2